CleanPipe™ jointing guidance

Using CleanPipe™ in trenchless installations



Attach the towing head directly to the leading end of the pipe coil. This operation is undertaken without removing the CleanPipe™ seals, located internally, a short distance from the pipe ends.



The pipe remains sealed throughout the whole installation procedure. Contamination from the installation process remains outside the factory seal.



After the installation is complete, CleanPipeTM can be pressure tested without the need to fit end caps. De-pressurise the pipeline before cutting the pipe ends.



Cut the pipe ends beyond the arrows which identify the cutting position on the label. This removes the seals, ready for the pipe to be joined using Radius Systems' fittings.



Prepare the pipe ends following the ProFuse® pipe preparation for electrofusion jointing above. Follow industry best practice and water industry procedures to make the joint and cleanse and test the pipeline.

